

place
barcode



12" Xpress Cut

Heat Transfer Vinyl

ADHERES TO:



100%
Cotton



100%
Polyester



Poly/Cotton
Blends



Lycra®/Spandex

CUT INSTRUCTIONS:

- ◀ **Graphtec:** Blade: 45°, Force: 8-9, Tool: CB09+0, Speed: 30 cm/s
- ◀ **Silhouette Cameo:** Blade: Standard 2, Material: Heat Transfer, Smooth, Speed: 8, Force: 4
- ◀ **Brother ScanNCut:** Blade: Standard 2, Cut Speed: 1, Cut Pressure: 4
- ◀ Cut in reverse

APPLICATION INSTRUCTIONS:

- ◀ Cover with Heat Transfer Cover Sheet or Multipurpose Paper
- ◀ Preheat garment for 2-3 seconds
- ◀ Apply design at 120°C/250°F
- ◀ Use medium pressure for 5 seconds
- ◀ Peel carrier hot or cold

WASHING INSTRUCTIONS:

- ◀ Wait 24 hours before first wash
- ◀ Machine wash cold / mild detergent
- ◀ Dry on normal dryer setting
- ◀ Do not dry clean or bleach

Coastal
BUSINESS SUPPLIES

800.562.7760
coastalbusiness.com

