

# ImageClip Inkjet Transfer Paper

for **Light Colors**

## Before you begin

Use product in well-ventilated area. Keep out of high humidity and away from moisture. Store in a cool, dry place. Use cotton or poly/cotton fabrics. Inkjet and Laser Printer required. Best if used on 100% cotton or cotton/poly blend.

## Printing Instructions

### 1. Preparing Image

Print your image on the Image Clip for Inkjet Transfer Paper with your inkjet printer. Print in reverse/mirror mode.

### 2. Print Negative of image

Now print a negative version of your same image (original orientation, not reversed), this time on regular paper with your laser printer. See image and description below for directions on turning your image into a negative. For other programs, see your manual.

**Adobe Photoshop:** Rotate the image back to the un-mirrored version. Select the magic wand tool and click the wand on the background; then, in the "select" menu, choose "similar". All the background should now be selected. In the "edit" menu, choose "fill", and then choose black in the "contents box". The background should now be black. In the "select" menu, choose "inverse" to highlight the image area. In the "edit" menu, choose "fill" and then choose white from the "contents box." The background should be black and the image should all be white. Print this negative image on plain paper with a laser printer.



Inkjet Image



Laser Negative



Garment Transfer

## Transferring Instructions

### 1. Preparing for Transfer:

Step 1- Align the printed side of the negative (in registration) against the printed side of the IMAGE CLIP™ for Inkjet Heat Transfer Paper. Use a heat press at 225 F for 30 seconds with firm pressure to press the papers together. Cool before separating the papers. Trim any un-weeded areas. (The weeding is done only in the areas covered by the black negative.) Discard the paper with the laser negative.

Step 2- Transfer the Image Clip for Inkjet Transfer Paper with your newly weeded image to your garment using a heat press for 30 seconds at 375 degrees F, firm pressure.

### 2. Peel & Wear

-Cool peel. Peel the transfer after cooling. For best results, stretch transfer immediately after peeling.

### Before Washing

Leave finish item for at least 24 hours before wash. Wash inside out in cold water. Dry at normal heat settings. Do not use bleach, fabric softener, or harsh detergents. Do not iron directly over transfer.

**No polymer border!**

**IMPORTANT:** We thoroughly test each of our products on various substrates using different transfer equipment. However, it is impossible for us to duplicate all variables using all substrates and transfer equipment. Therefore, it is essential that you test the paper prior to production using your equipment, methods, and substrate material. Heat presses vary in accuracy. Conduct tests to determine the best time and temperature to use with your equipment. Please keep in mind that the Seller's and Manufacturer's maximum obligation shall be to replace any paper that has proven to be defective. Neither the Seller nor the Manufacturer shall be liable for injury, direct or consequential, arising out of the use of, or inability to use the paper.